



# Comodo



## **COMODO** - DESIGNED BY PAUL ROGERS DESIGN STUDIO

Experience the epitome of luxury with the Comodo sofa, where indulgent comfort meets cutting-edge design. Our Comodo sofa redefines relaxation with its seamlessly integrated armrest lift mechanism, putting effortless customization at your fingertips.

For grand interiors and those who seek an extra layer of indulgence, there's the "Comodo Luxe." This larger-than-life version of the Comodo Sofa is a testament to the art of extravagance and comfort. Its dimensions are tailored for those spacious and luxurious living areas where size matters, and every element needs to make a statement.



## COMODO



**BACK**  
105 X 90 X 90



**CORNER**  
90 X 90 X 90



**1 SEATER (L)**  
120 X 90 X 90



**1 SEATER (R)**  
120 X 90 X 90



**CHAISE LONGUE (L)**  
120 X 180 X 90



**CHAISE LONGUE (R)**  
120 X 180 X 90

## COMODO GRANDE



**BACK**  
115 X 100 X 90



**CORNER**  
100 X 100 X 90



**1 SEATER (L)**  
130 X 100 X 90



**1 SEATER (R)**  
130 X 100 X 90



**CHAISE LONGUE (L)**  
130 X 190 X 90



**CHAISE LONGUE (R)**  
130 X 190 X 90



## UPHOLSTERY



Fabric

## COMFORT



HR Foam



Down

## OPTIONS



Black/Natural leg

## L x D x H

COMODO

seat depth 76 cm

seat height 42 cm

## L x D x H

COMODO GRANDE

seat depth 86 cm

seat height 42 cm

## CUSHIONS

For each seating module there is one cushion of 105x30 cm included.

## MATERIAL & CONSTRUCTION

Seat and back frame made in solid beech wood. Back frame is covered with coldfoam filling and wadding. Seat is made with zig-zag springs, felt, cold-foam and wadding. The module is upholstered in high-quality textiles, with a thin lining of down underneath. Modules are kept together with connecting metal brackets.

Different upholsteries may have different looks, and some fabrics may wrinkle slightly around the curved seat.

## CARE & MAINTENANCE

For textile upholstered versions: In case of stains, we generally recommend removing non-greasy stains by carefully dabbing with a lint-free cloth or sponge wrung out in clean warm water. If necessary, clean by dabbing with soapy water made with a little dish soap. Finally, dab the surface with clean water.